

- 1) Scan channel 1, the scanner will have di di di di... sound.
- 2) Take out the receiver and plug it again, then the di di sound will be stopped Then you can start to scan the barcodes



\$RF#CH00

Channel